


# STI (4.5mm) NON-BLOW BACK



1-01	Body Seat	1	1-14	Mag. Catch	1	1-34	Screw	1	3	Barrel Combination	7-01	Valve Chamber	1	
1-02	Body Cover	1	1-16	Safety Catch	1	1-35	Axis	1	3-01	BB Carry Parts	1	7-02	Valve Cover	1
1-03	Hammer Stopper	1	1-17	Back Cover Catch	1	1-36	Screw	1	3-04	Outer Barrel	1	7-03	Valve Ring	1
1-04	Frame	1	1-19	Trigger Connector	1	1-37	Screw	2	3-05	BB Holder	1	7-04	Piercer Seal	1
1-05	Grip(L)	1	1-20	Safety Catch	1	1-38	Stopper Spring	1	3-06	Internal Barrel	1	7-05	Fixing Ring	1
1-06	Grip(R)	1	1-21	Fixing Axis	1	1-39	Recoil Spring	1	3-07	BB Pusher	1	7-06	Valve Seal	1
1-07	Back Cover	1	1-22	Washer	1	1-40	Screw	1	3-09	Barrel Tip	1	7-07	O-ring	1
1-08	Recoil Spring Guide	1	1-23	Trigger Spring	1	1-42	Fixing Axis Spring	1	1-29	Axis	1	7-08	O-ring	1
1-09	Recoil Spring Guide Cover	1	1-24	Slide Stop Spring	1	1-43	Axis	1	4-01	Hammer	1	7-09	Washer	1
1-10	Slide Cover	1	1-25	Hammer Spring	1	2-01	Slide	1	4-02	Attacked Block	1	7-10	Filter	1
1-11	Trigger	1	1-27	Back Cover Catch Spring	1	2-02	Front Sight	1	5	Mag. Combination	8-01	7-11	Piercer	1
1-12	Slide Stop	1	1-28	Safety Catch Spring	1	2-03	Aiming Hole	1	5-01	Mag. Body	1	7-12	Valve	1
									5-02	Mag. Cover	1	7-13	Valve Spring	1
									5-03	BB Follower	1	8	Knob Combination	
									5-04	Mag. Base	1	8-01	Knob Seat	1
												8-02	Knob Cover	1
												8-04	Piercing Level Screw	1
												8-05	Axis	1
												8-06	Screw	2