



DIANA®

Mayer & Grammelspacher GmbH & Co.KG
 Postanschrift:
 Oesterweg 21 | 59469 Ense

Service:
 Auf den Geeren 23 | 59469 Ense

Telefon: 02938 97837 - 60
 Telefax: 02938 97837 - 162
 info@diana-airguns.de

www.diana-airguns.de

POS-No.	Art-No.	Description	Qty.
1	03.01.04.0212	silencer 4.5	1
1	03.01.04.0222	silencer 5.5	1
2	03.04.02.0003	front sight	1
3	03.07.03.0045	rear sight base pin	1
4	03.04.03.0022	rear sight	1
5	03.04.03.0030	rear sight base	1
6	03.07.01.0347	elevation screw	1
7	03.07.01.0088	windage screw	2
8	03.04.03.0031	rear sight block	1
9	03.08.02.0091	rear sight base spring	1
10	03.01.04.0005	air reservoir mount	1
11	03.07.01.0161	air reservoir mount fixing screw	2
12	04.02.01.0008	barrel 4.5	1
12	04.02.01.0009	barrel 5.5	1
13	03.05.01.0031	barrel O ringD7.9-0.8	2
14	03.05.01.0048	breech O ring 4.5	1
14	03.05.01.0047	breech O ring 5.5	1
15	03.07.01.0119	barrel fixing screw	4
16	03.07.01.0114	safety screw	1
17	03.07.01.0100	rear sight screw2	1
18	03.07.07.0005	insert magnet2	1
19	03.01.04.0080	breech 4.5	1
19	03.01.04.0081	breech 5.5	1
20	03.05.01.0035	bolt o ring	2
21	03.01.02.0126	bolt (gsg)	1
22	04.02.03.0022	firing pin 4.5	1
22	04.02.03.0023	firing pin 5.5	1
23	03.01.04.0128	piston cover	1
24	03.01.04.0070	piston rod	1
25	03.08.02.0098	piston spring	1
26	03.01.04.0017	piston screw bushing	2
27	03.01.01.0202	bolt screw	1

POS-No.	Art-No.	Description	Qty.
28	03.01.01.0200	piston screw	1
29	03.01.01.0124	piston	1
30	03.05.05.0008	rubber ball	1
31	03.05.01.0088	valve connector O ring	2
32	03.01.04.0172	valve connector	1
33	04.02.05.0011	air tube assembly	1
34	03.01.01.0396	gas cylinder rod	1
35	03.05.01.0113	gas cylinder rod O ring	2
36	03.07.05.0012	detent ball	1
37	03.01.04.0396	strength base	1
38	03.01.02.0113	fixing pin	1
39	03.03.05.0073	strength roll	1
40	03.04.04.0296	strength cover	1
41	03.07.01.0378	screwM4*16	1
42	03.07.02.0025	nut M4	1
43	03.07.01.0377	fixing cover screw	4
44	03.01.04.0482	fixing cover	1
45	03.05.01.0114	fixing cover O ring	1
46	03.01.05.0104	puncture pin nut	1
47	03.01.01.0395	puncture pin2	1
48	03.01.04.0397	puncture base	1
49	03.01.05.0011	puncture pin nut 2	1
50	03.01.01.0394	puncture pin	1
51	03.05.01.0064	stopper ring	1
52	03.05.01.0087	O ringD13-3	1
53	03.01.04.0398	valve1	1
54	03.05.01.0033	valve O ring	1
55	03.08.02.0086	valve spring	1
56	03.01.06.0005	exhaust valve core cover	1
57	03.01.05.0008	exhaust valve core	1
58	03.07.03.0041	exhaust valve core pin	1
59	04.02.02.0024	valve2	1

POS-No.	Art-No.	Description	Qty.
60	03.01.01.0118	trigger base	1
61	03.07.01.0160	trigger base screw	1
62	03.07.03.0043	trigger pin	2
63	03.07.01.0120	trigger screw	2
64	03.07.01.0159	breech lower screw	1
65	03.03.03.0089	sear	1
66	03.08.02.0090	trigger spring	1
67	03.07.01.0202	trigger screw1	1
68	03.03.03.0032	trigger	1
69	03.07.01.0201	trigger adjust screw	1
70	03.04.01.0115	PP stock	1
71	03.01.04.0132	trigger guard	1
72	03.07.01.0162	trigger guard screw	1
73	03.08.02.0064	safety spring	1
74	03.07.05.8010	detent ball 3.175	1
75	03.01.02.0007	right safety button	1
76	03.01.02.0008	left safety button	1
77	03.07.01.0144	wood stock screw1	1
78	03.07.01.0145	wood stock screw2	1